

Denon DN-F650R Firmware Installation instructions

v.4.07

If you are using the DN-F650R with the RC-F400S, this update must be performed first.

To check the firmware version on the DN-F650R, please follow the instructions below.

1. Power on the DN-F650R.
2. Press and hold the 'Menu / Store' until the menu appears.
3. Turn the SELECT knob counter clockwise until "F/W VERSION" is displayed.
4. Press the SELECT knob to display the current version number.

To update the firmware on the DN-F650R, please follow the instructions below.

1. Extract the update file folder.
2. You will obtain the **DN-F650Rup.bin** update file once extracted.
3. Drag and drop this file to any SD card.
4. Place the SD card in the DN-F650R and power the machine on.
5. The machine should prompt you for the update. Select 'Yes'.
6. Press the jog wheel to start the update process.
7. Once the update is completed the machine will reboot itself.
8. Remove the update file from the card.