

# DN-300C MKII

## Firmware Upgrade Instructions

1. Add the “**DN-300CB.bin**” file to the root folder of a FAT32 formatted USB drive (NTFS format is not supported).
2. With the unit powered off, connect the USB drive to the rear USB port. Move the switch next to the USB port to “UPDATE”.
3. Power on the DN-300C MKII. Turn the knob on the right until the display says “**UPDATE Y**” and press in the knob to begin the firmware update.
4. The display will show the progress of the update. Once complete, the display will show “SUCCEED” and the unit will restart automatically.
5. Power off the DN-300C MKII and move the rear switch back to “**NORMAL**”.
6. To confirm the updated firmware version, power the DN-300C MKII on. Press in and hold the SELECT knob. Turn the knob until the display shows <System Version> and press in the SELECT knob to view the installed firmware version.

This firmware improves performance, bug fixes, and adds the ability to view song titles before selecting for playback.