



## DN-700CB

Latest CD Firmware Version: 3.33

### Firmware Update Instructions

#### To update the CD firmware on your DN-700CB:

1. Download the latest DN-700CB CD firmware update file from [denonpro.com](https://www.denonpro.com).
2. Add the firmware update file to the root folder of a FAT32-formatted USB flash drive.
3. With the DN-700CB powered off, insert the USB flash drive into the *front panel* **USB slot**.
4. Power on DN-700CB.
5. Press and hold the **jog dial** to open the menu.
6. Use the jog dial to select **SW Update**, then press it to select.
7. Use the **jog dial** to select **CD Update**, then press it to select.
8. Use the **jog dial** to select **Yes** and press it to begin the firmware update, or select **No** to cancel.

**Important:** Do not power off the unit while the firmware update is in progress.

9. Once the update is complete, power off the unit and remove the USB flash drive.

### Technical Support

For additional help, visit [denonpro.com/support](https://www.denonpro.com/support).