


# Front panel



❶ Power operation button (ON/STANDBY)

❷ Headphones jack (PHONES)

❸ USB port

❹ DIMMER button

❺ ZONE2 SELECT button

❻ ZONE2 ON/OFF button

❼ KEY LOCK button

❽ QUICK SELECT buttons

❾ STATUS button

❿ SLEEP button

⓫ iPod play button (iPod ►)

⓬ V.AUX INPUT connectors

⓭ AUX-HDMI connector

⓮ MASTER VOLUME control knob

⓯ Display

⓰ Remote control sensor

⓱ SOURCE SELECT knob